



<b>Model</b>	<b>FL-S10(Soprano) / FL-C10(Concert) / FL-T10(Tenor)</b>		
<b>Size</b>	Soprano/Concert/Tenor	<b>Rosette</b>	Red tortoise shell inlay
<b>Finish</b>	Glossy	<b>Binding</b>	Red tortoise shell
<b>Top</b>	Laminated Mahogany	<b>Strings</b>	Aquila nylon
<b>Back &amp; Sides</b>	Laminated Mahogany	<b>Logo</b>	Acrylic inlay
<b>Fretboard</b>	Rosewood	<b>Machine Head</b>	Die-cast black
<b>Bridge</b>	Rosewood	<b>Fret Markers</b>	Acrylic inlays
<b>Neck</b>	Okoume	<b>Color</b>	Wood
<b>Number of Frets</b>	Soprano 15 Concert 18 Tenor 18	<b>Scale Length</b>	Soprano 350mm(14") Concert 385mm(15") Tenor 432mm(17")
<b>Nut</b>	OX bone	<b>Saddle</b>	OX bone
<b>Optional Accessories</b>	gig bag, tuner, strap, picks, polishing cloth, strings, equalizer		